

FLOORING AFTERCARE MANUAL

Aftercare Instructions for FLOORINGS

Vinyl, Laminate & Engineered Timber

- DAILY cleaning with vacuum cleaner, broom, damp cloth or mop.
- ALWAYS remove excess water on floor IMMEDIATELY.
- Remove normal stains with NEUTRAL detergent.
- NO wet-washing.
- USE soft felt pads under furniture legs or chair legs to avoid scratches.
- USE a doormat in front of entrances to reduce the amount of dirt, grit and moisture.
- USE soft treads/rollers on rollers of office chairs and file trolleys.

Applicable to Vinyl only

- DO NOT use rubber-backed or coco-fiber mats as they may cause yellow stains
- DO NOT expose to direct sunlight to avoid discoloration

Engineered Timber

- DO NOT use steam cleaners.
- Damaged areas can be repaired by filling with a soft wax that matches the colour of the floor.
- Sanding of the floors can be done to completely renovate the engineered timber floor. Appropriate lacquer or oil products can be used for subsequent surface treatment.

Outdoor WPC Decking

REGULAR water washing is recommended.

Please request for a detailed maintenance guide from the salesperson once the project is confirmed, as it may differ depending on the brand.